Hi-Capacity® 90-Watt Universal Laptop Adapters

- Manufacturer/Model Compatibility Guide -

AC-5101

ACDC5001

Hi-Capacity™ POWER PRODUCTS

Choosing and connecting adapter tips:

1. Locate the specified tip from the tip bundle provided. Each tip is clearly numbered ***(Fig. 1).***
2. Connect the selected tip to the end of the output cable, making sure that the pins on the tip are aligned with the holes in the cable ***(Fig. 2)***. The ridge on the inside of the tip should align with the groove in the output cable connector. Also make sure that the tip is pushed all the way into the cable's connector.
3. Plug the power tip into your notebook computer.
4. Connect the adapter's input cord to the AC or DC power outlet. *(Note: Depending on your adapter model, DC connectivity may not be available.)*

Fig. 1:

Fig. 2:

CAUTION: The use of an incorrect tip may damage your laptop. Do not use this product if you cannot locate your laptop model in the Tip Compatibility Guide included with this adapter. If you still have questions, contact our toll-free help line for assistance at (800) 437-7777. This power adapter is not compatible with Mac computers.

IMPORTANT: If the adapter's LED does not turn on, or if it blinks, discontinue use and contact our toll free Customer Support line at (800) 437-7777.

TO DETERMINE THE CORRECT CONNECTOR TIP TO USE FOR YOUR LAPTOP:

1. Find the brand of laptop in the alphabetized list. Larger manufacturer model families are listed in a separate column for easier location.
2. Find the model name and/or number of your laptop in the manufacturer section. Be sure to check all tip listings for an exact match for your laptop's model.
3. Match the connector tip number you find in the column next to your model number with the number molded into the connector tip.
4. Select this tip from the assortment included with your adapter and connect it securely to the adapter's output cord. See the previous page for complete instructions on fitting the power tip and output cord together.

MANUFACTURER INDEX

Acer 1
Acer Aspire 1
Acer Travelmate 1
AMS Tech 2
AST 2
Asus 2
Averatec 3
Compal 3
Compaq 3
Compaq Business Notebook 4
Compaq Presario 5
Dell 6
E-Machines 7
Fujitsu 7
Gateway 7
Hewlett Packard 9
Hewlett Packard Business Notebook 9
Hewlett Packard Pavilion 10
IBM 14
IBM Thinkpad 14
Lenovo 14
Lenovo Thinkpad 14
Packard Bell 15
Panasonic 15
Sony 15
Sony VAIO PCG 16
Sony VAIO VGN 17
Toshiba 18
Toshiba Portege 19
Toshiba Satellite 19
Toshiba Tecra 22
Twinhead 22
Winbook 23

ACER

Tip	Model Name / Number
9	• Extensa: 515
32	• AcerNote: 330T • Extensa: 5120, 5210 • Ferrari: 1000, 5000, 5005 • AS4730-4857 • EX4420-5237, EX4420-5963, EX4620-4605, EX4630-4658, EX5420-5687
41	• AcerNote: 367D, 367T, 390, 390A, 391, 392, 393, 394, 395, 1100LX, 1120LX • Extensa: 365, 366D, 367D, 368D, 390, 390C, 390CX, 393, 900, ESS3-391T • Ferrari: 3000, 3000LMi, 3200, 3400LMi, 4000

ACER ASPIRE

Tip	Model Name / Number
5	• 3002WLCi, 3003, 3003LCi, 3003WLCi, 3003WLMi, 3004, 3005, 3009, 3020, 3022WLMi • 5002, 5002WLMi, 5003, 5050, 5050-3785, 5050-5278, 5672
32	• 1200, 1360, 1410, 1520, 1640, 1640Z, 1642, 1680, 1681WLCI, 1690, 1691WLMi, 1800 • 2000, 2010, 2012WLCi, 2012WLMi, 2020, 2200 • 3000, 3002, 3002LCi, 3030, 3050, 3050-1047, 3050-1594, 3100, 3500, 3600, 3610, 3612, 3613, 3618, 3618AWLCi, 3620, 3623, 3624, 3630, 3634WLMi, 3680, 3680-2022, 3680-2633, 3690, 3690-2710 • 4310, 4315, 4520, 4520-5803, 4710, 4715, 4720, 4920 • 5000, 5030, 5100, 5100-3357, 5100-3372, 5100-3577, 5100-3583, 5100-3825, 5100-3959, 5100-5328, 5100-5540, 5100-5840, 5100-5873, 5110, 5110-5447, 5113WLMi, 5310, 5500, 5520, 5520-5912, 5520G, 5550, 5570, 5570-2067, 5570-2609, 5570-2758, 5570-2792, 5570-2935, 5570-4421, 5570z, 5580, 5580-6432, 5610, 5610-2273, 5610-4537, 5610-4610, 5610-4648, 5610Z, 5630, 5633WLMi, 5670, 5680, 5680-6509, 5710G, 5710Z, 5710ZG, 5720, 5720-4126, 5720G, 5910G, 5920, 5920G • 7100, 7104, 7220, 7520, 7520G, 7720, 7720-6395, 7720G • 9300, 9400, 9410-4923, 9502, 9502WSMi, 9503, 9503EWSMi, 9504, 9504EWSMi, 9504WSMi
41	• 1300, 1350 • 5600

ACER TRAVELMATE

Tip	Model Name / Number
9	• 512DX, 512T
32	• 210, 210T, 210TER, 211T, 212T, 212TE, 212TXV, 213T, 213TXV, 220, 223X, 223XC, 225X, 225XC, 225XV-Pro, 230, 233XC, 260, 261, 261XV-XP, 270, 270xv, 280, 290, 290 series, 291LCi, 291LCi-G, 291LMi-G, 291LMi-G, 292LCi, 292LMi-V68MB • 330, 330T 340T, 350, 351TEV, 360 • 420, 430 • 500, 506, 506DX, 5100, 520, 521T, 521TE, 521TXV, 522, 5220, 525, 525TXV, 527TXV, 529TXV, 530 • 600, 602, 602TER, 603, 610, 620, 630, 650, 660, 662LMi

ACER TRAVELMATE

Tip	Model Name / Number
32	• 730, 732, 730TXV, 732TLV, 738TLV, 739TLV, 740 • 800, 800LCi, 802LCi, 803LCi, 804LMi • 1362LCi, 1362WLMi, 1363WLCi • 2300, 2350, 2400, 2410, 2413, 2420 series, 2423, 2424, 2430, 2440, 2450, 2480 • 3000, 3000LMi, 3010, 3200 series, 3200LMi, 3210, 3220, 3230, 3260, 3270, 3400LMi • 4000, 4005WLMi, 4006WLMi, 4011, 4020, 4021, 4060, 4100, 4150, 4200, 4200-4091, 4200-4320, 4200-4493, 4200-4854, 4202, 4202WLMi, 4220, 4230, 4230-6499, 4230-6704, 4500, 4650, 4670, 4672WLMi • 5310, 5320, 5520, 5520G, 5600, 5630, 5670, 5710, 5710G, 5720, 5720G • 6000 series, 6000, 6003LMi, 600TER, 6410, 6410-6189, 6410-6248, 6460, 6460-6263, 6460-6752, 6592, 6592-8204 • 7220, 7220G, 7320, 7520, 7520G, 7720, 7720G • 8000 series, 8000, 8002LCi, 8003LMi, 8006LMi, 8100, 8200, 8202, 8202WXMi, 8204, 8204WLMi, 8205, 8210, 8215, 8216 • 9411AWSMi • a550, a551, alpha 550, alpha 551 • C100 series, C100, C102T, C102Ti, C104, C110, C110TCi, C110Ti, C200, • C300 series, C300, C300Xci, C300Xmi, C301, C301Xmi, C301XMib, C302, C302Xci, C302Xmi, C310
41	• 240, 244LCi, 244LC-XPP, 250, 250PE, 252ELC, 252ELCi, 254ELCi • 4404

AMS TECH

Tip	Model Name / Number
32	• Rodeo: 3000 series, 3000CX, 3000ECX, 3015ECX, 3020ECX, 3030ECX, 3035CX, 3035CX98, 3037CX, 3038CX, 3040ECX, 3042ECX, 3052ECX, 3062ECX, 3072ECXA, 5000ECX, 5010ECX, 5020ECX, 5030ECX, 5032ECX, 5042ECX, 5052ECX • Travelex: 105 • TravelPro: 101CT, 255CT, 255CX, 256CXA, 257CXA, 2500, 2550, 2570, 2580, 2500CX, 2500CX98, 2550CT98, 2550CX, 2550CX98, 2595CXA, EX105CT
41	• Rodeo: 1000CT, 1000CX, 1010CT, 1010CX, 1010CXNT, 7000, 7030ECX, 7620, 7630ECXDNT, 7640XL • TravelPro: 180, 1900

AST

Tip	Model Name / Number
3	• Ascentia: A, A40, A41, A42, A43, A51, A60, A70, AD40, J, J10, J20, J30, J50, J55, M, M5200T, M5260X, M6000

ASUS

Tip	Model Name / Number
5	• A3 series, A3E, A3G, A3L, A3N • A3000 series, A3000E, A3000G, A3000L

ASUS

Tip	Model Name / Number
5	• F7000 • Grandio F7400 • L5, L5000, L5000C, L5000D, L5000G, L5800C, L5800DF, L5800GA, L5800GM, L5800GX, L5900, L5C, L5D, L5G, L7000, L7000C, L7200, L7300, L8400C-800C, L8400C-800D, L8400K • Z91, Z9100 Series, Z9100E, Z9100ER, Z9100G, Z9100L, Z9100N, Z91E, Z91ER, Z91G, Z91L, Z91N
41	• A9, A9RP, A9T, A3000N • G2p, G2s

AVERATEC

Tip	Model Name / Number
41	• 1000 series • 2260 • 3150HW • 3260 series • 3270 series • 3280 series • 3700 series, 3715EDI • 3800 series • 4100 series, 4200 series • 5110 series, 5110H, 5110HX, 5110P • 6100A series, 6200 series, • AV1020-ED1, AV1050-EB1, AV3100 series, AV3120V, AV3150H, AV3150HS, AV3150P, • AV3200 series, AV3220H1, AV3225HS, AV3250H1, AV3250HS, AV3250HX, AV3250PX, AV3255P1, AV3270EH1, • AV3300 series, AV3360-EG1, AV3360-EH1, AV3500T60, AV4155-EH1, AV5500, AV6110, AV6200H60, AV6210X60, AV6235, AV6240 • C3500 • SL3150HD-01

COMPAL

Tip	Model Name / Number
32	• CL11 • N-30N3
41	• N20U, N30B2, N30W, N32NC, N38N, N38n2-14 • TS30H, TS30I, TS30I3, TS30T, TS30T3, TS30W

COMPAQ

Tip	Model Name / Number
5	• Armada: 110, 110S, E500, E500s, E700, M300, M700, V300 • Evo: N110, N150, N200, N400c, N410c, N600, N600c, N610c, N620c, N800, N800 series, N800c, N800v, N800w • Prosignia: 170, 190 • Tablet PC: TC1000, TC1100, TC4200 • NX9020

COMPAQ

Tip	Model Name / Number
28	• Evo: N1000 series, N1000c, N1000v, N1010v, N1015v, N1020v, N1050v
41	• Armada: 2940 • Evo: N105, N 115, N160, N180 • Prosignia: 150 • NX9010, NX9030
55	• Pavilion: DV5-1007tx, DV5-1008ax, DV5-1008ca, DV5-1020el • Tablet PC: TC4400

COMPAQ BUSINESS NOTEBOOK

Tip	Model Name / Number
5	• NC4000, NC4010, NC4200, NC6000, NC6100, NC6120, NC6125, NC6200, NC6220, NC6230, NC6325, NC8000, NC8200, NC8230 • NW8000, NW8200, NW8240 • NX4800, NX4820, NX5000, NX6100, NX6110, NX6120, NX6125, NX6130, • NX7000 series, NX7000, NX7010, NX7100, NX7300, NX8200, NX8220, NX9020, NX9030, NX9040
41	• N1050V • NX9000, NX9005, NX9010
55	• 2510p • 6510b, 6515b, 6535B, 6710b, 6710s, 6715b, 6715s, 6730S, 6910p • NC2400, NC4400, NC6110, NC6140, NC6320, NC6400, NC8430 • NW8440, NW9440 • NX6115, NX6310, NX6315, NX6320, NX6325, NX6330, NX7400, NX8410, NX8420, NX9420

COMPAQ PRESARIO

Tip	Model Name / Number
5	• 2200, 2201, 2800, 2204US, 2210CA, 2210US, 2227US, 2231AP, 2231US, 2800 series, 2800CA, 2800T, 2800US, 2801CL, 2805US, 2811CL • A931NR, A940NR • B1801TU, B1802TU, B1803TU, B1804TU, B1805TU, B1806TU, B1807TU, B1808TU, B1809TU, B1810TU, B1811TU, B1812TU, B1813TU, B1814TU, B1815TU, B1816TU, B1817TU, B1818TU, B1819TU, B1820TU, B2801TX, B2802TX, B2803TX, B2804TX, B2805TX, B2806TX, B2807TX, B2808TX, B2809TX, B2810TX, B2811TX, B2812TX, B2813TX, B2814TX, B2815TX, B2816TX, B2817TX, B2818TX, B2819TX, B2820TX • C302NR, C303NR, C304NR, C306US, C501, C502, C502US, C551NR, C552US, C555NR, C563NR, C571NR, C700 Series, C714NR, C727US, C751, C756, C762NR, C769US, C770US, C771US, • F500 Series, F557US, F572US • F700 Series, F730US, F750, F750US, F756NR, F761CA, F762NR, F763NR, F767NR • M2000 series, M2005, M2007, M2010, M2105US, M2108, M2305, M2401 • V2000 series, V2000Z, V2010US, V2030US, V2100, V2110CA, V2110F, V2140CA, V2140F, V2140US, V2205, V2210CA, V2220US, V2306, V2309, V2310, V2311, V2312, V2321, V2401, V2402, V2403, V2405, V2405US, V2410, V2414, V2424, V2552US, V2555, V2565, V2570, V2582US, V2602XT, V2606, V2607CL, V2610, V2615US, V2630US, V2658US, V2665US, V2670US,

COMPAQ PRESARIO

Tip	Model Name / Number
5	V2710US, V3000, V3000T, V3000Z, V3002XX, V3010CA, V3010TU, V3010US, V3015CA, V3015NR, V3016US, V3017LA, V3018CL, V3018US, V3019US, V3020CAI, V3020US, V3025AU, V3029AU, V3030CA, V3030US, V3033AU, V3070TU, V3110CA, V3120TU, V3122TU, V3145AU, V3172TU • V3500 Series • V4000 series, V4000, V4001, V4002, V4003, V4004, V4005, V4015, V4020, V4310, V4435, V4440US, V5000 series, V5000T, V5000Z, V5005, V5015, V5088, V5099, V5101US, V5102, V5105, V5108CU, V5115US, V5119, V5120, V5160US, V5189, V5201US, V5208CA, V6000, V6000T, V6000Z, V6001XX, V6030US, V6048CL, V6101US, V6105NR, V6107US, V6110CA, V6110US, V6120CA, V6120US, V6130US, V6133CA, V6133CL, V6137US, V6143CL, V6171CL, V6205NR, V6210US, V6305NR • V6500 Series • X1000 series, X1000, X1010US, X1015, X1015US, X1018CL, X1020US, X1030, X1030US, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1039AP, X1040, X1040US, X1041AP, X1058CL, X1360US, X1460US
28	• 900 series, 900, 900US, 905, 905US, 906US, 910, 910US, 912, 912rsh, 918, 918rsh, 920, 920US • 1500 series, 1500, 1500T, 1500US, 1501CL, 1505US, 1510US, 1516US, 1525US,
32	• 300, 305, 306
41	• 12XL series, 12XL, 12XL115, 12XL125, 12XL300, 12XL310, 12XL325, 12XL326, 12XL327, 12XL4, 12XL400, 12XL401, 12XL405, 12XL410, 12XL420, 12XL426, 12XL427, 12XL430, 12XL500, 12XL505, 12XL510 • 14XL series, 14XL240, 14XL245, 14XL340, 14XL345 • 17XL series, 17XL265, 17XL275, 17XL360, 17XL362, 17XL365, 17XL375, 17XL460, 17XL465, 17XL475, 17XL570 • 18XL series, 18XL280, 18XL380, 18XL390, 18XL580, 18XL590 • 80XL550 • 700 series, 700, 700US, 700Z, 701CL, 705US, 711cl, 720US, 721CL, 722US, 723RSH, 725US, 730US, 732US, 701, 705, 710, 715, 725 • 800 series, 800, 800XL • 1000, 1010, 1020, 1030, 1040, 1050, 1060, 1065, 1070, 1075, 1080, 1081, 1090, 1090ES, • 1200, 1200T, 1200US, 1200XL, 1200XL101, 1200XL102, 1200XL103, 1200XL104, 1200XL105, 1200XL106, 1200XL109, 1200XL110, 1200XL111, 1200XL118, 1200XL119, 1200XL125, 1200XL126, 1200XL127, 1200XL3, 1200XL300, 1200XL325, 1200XL401, 1200XL404, 1200XL406, 1200XL408, 1200XL409, 1200XL420, 1200XL423, 1200XL500, 1200XL505, 1200XL510, 1200XL515, 1200XL526, 1201AP, 1201Z, 1207, 1210, 1214, 1214SR, 1215, 1216, 1220, 1221, 1230, 1232, 1234, 1235, 1236, 1237, 1240, 1242, 1244, 1245, 1246, 1247, 1250, 1255, 1256, 1260, 1262, 1266, 1267, 1270, 1272, 1273, 1274, 1275, 1277, 1278, 1279, 1280 • 1400 series, 1400, 1400T, 1456 • 1600, 1600XL145, 1610, 1611, 1615, 1620, 1621, 1622, 1625, 1626, 1630, 1635, 1640, 1650, 1655, 1665, 1670, 1672, 1675, 1680, 1681, 1682, 1685, 1687, 1688, 1690, 1692, 1693, 1694, • 1700, 1700T, 1700XL573, 1710 (new version), 1710LA, 1710SB (new version), 1710TW, 1714EA, 1720US • 1800, 1800T, 1800T-800, 1800T-850, 1800XL, 1800XL190, 1800XL280, 1800XL380, 1800XL390, 1800XL481, 1805, 1810, 1825, 1827, 1830, 2100, 2155, 2176, 2195, 2500, 2540

> COMPAQ PRESARIO

Tip	Model Name / Number
41	• 2100 series, 2100AP, 2100CA, 2100LA, 2100US, 2101AP, 2101US, 2102AP, 2102EA, 2102US, 2103AP, 2103EA, 2104AP, 2104US, 2105AP, 2105CA, 2105EA, 2105LA, 2105US, 2106AP, 2106EA, 2106US, 2107AP, 2107EA, 2108EA, 2108US, 2109EA, 2110AP, 2110CA, 2110EA, 2110LA, 2110US, 2111AP, 2111EA, 2112AP, 2112EA, 2113AP, 2114AP, 2114EA, 2115AP, 2115EA, 2116AP, 2117AP, 2117EA, 2118AD, 2118EA, 2119EA, 2120AD, 2120AP, 2120EA, 2120LA, 2122AD, 2123AD, 2123AP, 2124AD, 2124AP, 2125AC, 2125AD, 2125AP, 2125EA, 2126AC, 2126AD, 2126EA, 2127AC, 2127AD, 2127EA, 2128AC, 2128AD, 2128EA, 2129AD, 2129EA, 2130AC, 2130AD, 2130AP, 2130EA, 2131AC, 2131AD, 2131EA, 2132AC, 2132RS, 2133AC, 2133AD, 2133AP, 2133EA, 2134AD, 2134EA, 2135AC, 2135AD, 2135AP, 2135CA, 2135EA, 2135US, 2136AC, 2136AD, 2136EA, 2136RSH, 2137AC, 2137AD, 2137EA, 2138AC, 2138AD, 2138EA, 2139AC, 2139AD, 2140AC, 2140AD, 2140AP, 2140CA, 2140US, 2141AC, 2141AD, 2141EA, 2142EA, 2143AD, 2143AP, 2144AD, 2144EA, 2145AD, 2145AP, 2145CA, 2145EA, 2145US, 2146AD, 2146EA, 2147AD, 2147EA, 2148AD, 2148EA, 2149AD, 2149EA, 2150AP, 2150US, 2151AD, 2151EA, 2153AP, 2154AP, 2154EA, 2155EA, 2155US, 2156EA, 2158EA, 2160EA, 2161EA, 2161US, 2162EA, 2162US, 2163EA, 2164EA, 2165EA, 2166EA, 2167EA, 2169EA, 2170US, 2172EA, 2173EA, 2175EA, 2175US, 2186RS, 2188CL, 2190US, 2195US, 2199US • 2500 series, 2500AP, 2500LA, 2505AP, 2510AP, 2510EA, 2510LA, 2511EA, 2512EA, 2515AP, 2515EA, 2516EA, 2520AP, 2520EA, 2521EA, 2525AP, 2525CA, 2525EA, 2525US, 2526EA, 2528CL, 2529CL, 2530AP, 2535AP, 2535QV, 2538CL, 2540AP, 2545AP, 2545US, 2550AP, 2555AP, 2555US, 2560AP, 2565AP, 2570US, 2575US, 2580US, 2585US, 2590US, 2594US, 2596US, 2597US, 2598US • 2700 series, 2700T, 2700US, 2701T, 2702TW, 2710US, 2715US, 2720US
55	• CQ50, CQ50-103NR, CQ50-105NR, CQ50-110US, CQ50-115NR, CQ50-215NR • CQ70-130ED, CQ70-100ER, CQ70-101TX, CQ70-102TU, CQ70-102TX, CQ70-103EB, CQ70-103EF, CQ70-103EM, CQ70-103TU, CQ70-103TX, CQ70-104TX, CQ70-105EB, CQ70-105EF, CQ70-105TX, CQ70-110EB, CQ70-110EF, CQ70-110EM, CQ70-110EO, CQ70-110ER, CQ70-110ES, CQ70-111CA, CQ70-115EE, CQ70-115EF, CQ70-115EO, CQ70-115ES, CQ70-116EA, CQ70-116EM, CQ70-117CA, CQ70-118CA, CQ70-118EF, CQ70-118EO, CQ70-118NR, CQ70-120EF, CQ70-120EM, CQ70-120EO, CQ70-120ES, CQ70-120US, CQ70-123EO, CQ70-124CA, CQ70-125EO, CQ70-127NR, CQ70-128NR, CQ70-130EG, CQ70-130EO, CQ70-134CA, CQ70-135EO, CQ70-140ED, CQ70-140EG, CQ70-150EG, CQ70-150EV, CQ70-158EZ • CQ119CA

DELL

Tip	Model Name / Number
3	• Latitude: LX450, XP, XP4100, XP4100C, XP4100CX, XP4100T, XP450C, XP475C, XP475D
23	• Inspiron: 1150, 1318, 1420, 1421, 1501, 1520, 1521, 1525, 1526, 1720, 1721, 5150, 5160, 6000, 6400, 8500, 8600, 9200, 9300, 9400, 300m, 500m, 510m, 600m, 630m, 640m, 700m, 710m, 740m, E1405, E1505, E1505n, E1705, XPS Gen2 • Latitude: 100L, 131L, ATG D620, D400, D410, D420, D430, D500, D505, D510, D520, D530, D531, D600, D610, D620, D630, D630 ATG, D630c, D630N, D631, D800, D810, D820, D830, X300, XFR D630, XT Tablet PC • Precision: M20, M2300, M60, M65, M70 • Studio: 15, 17, 1535, 1536, 1735, 1736

> DELL

Tip	Model Name / Number
23	• Vostro: 1000, 1310, 1400, 1500, 1510, 1700, 1710 • XPS: M1210, M1330, M140, M1530, M170, M2010
41	• Inspiron: 1000, 1200, 1300, 2200, 3000, 3200, 3500, 7000, 3500 D233 XT, 3500 D266 GT, 3500 D300 GT, 7000 D266 GT, 7000 D300 LT, 7000 series, B120, B130 • Latitude: 110L, 120L

E-MACHINES

Tip	Model Name / Number
28	• M2105, M5000, M5105, M5305, M5309, M5310, M5312, M5313, M5410, M6410, M6412, M6414, M6805, M6807, M6809, M6810, M6811
41	• eSlate: 400K, 450K • M2350, M5405

FUJITSU

Tip	Model Name / Number
32	• Amilo: A6600, A7600, A8600, DCY23, D6800, D6830, D7800, D8800, D8820
41	• Amilo: A1640, D7830, M4100, M6100, M6300, M6500, M6800, M7800, M-7800, M8800 • LifeBook: A Series, A1010, A4170, A4177, A4178, A4187, A4190, C1010, C1020, C2110, C2111, C2210, C2220, C2230, C4175, C6175, C6185, C6597, E2010, E4010, E4010D, E7000 series, E7000, E7010, E7110

GATEWAY

Tip	Model Name / Number
28	• 7405GH, 7405GX, 7410GX, 7422GX, 7422GZ, 7426GX, 7430JP, 7508GX, 7510GX • MX7515, MX7525, MX7527
41	• 400SD4, 450ROG, 450S, 450SX4, 450X • 600YG2, 600YGR • 3018GZ, 3040GZ, 3520GZ, 3522GZ, 3525GB, 3545GZ, 3550GH, 3550GZ, 3610GZ • 4012GZ, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 4028JP, 4030GZ, 450RGH, 4520GZ, 4525GZ, 4530GH, 4530GZ, 4535GX, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4541BZ, 4542GP, 4543BZ • 6010GZ, 6018GH, 6018GZ, 6020GZ, 6021GH, 6021GZ, 6022GZ, 6023GP, 6510GZ, 6518GZ, 6520GZ, 6525GP, 6531GZ, 6834MX7110GX • 7305GZ, 7324GZ, 7325GZ, 7326GZ, 7415GX • 8510GH, 8510GZ • C120X • CX200S, CX200X, CX210, CX210X, CX2608, CX2610, CX2615, CX2618, CX2619, CX2620, CX2720, CX2726, CX2728 • E-100M, E-100MG, E-100MSB, E-155C, E-155CG, E-265M, E-265MG, E-475M, E-475MG • M-24 • M-73, M-78

> GATEWAY

Tip	Model Name / Number
41	• M-150S Garnet Red, M-150S Pacific Blue, M-150S Slate Grey, M-150S SlateGrey Ridgeview • M-150X, M-150X Garnet Red, M-150X Pacific Blue, M-150X Pacific Blue Ridgeview, M-150X Slate Grey Ridgeview • M-150XL Pacific Blue Ridgeview, M-150XL Pacific Blue, M-150XL Slate Grey Ridgeview • M-151 Series • M-152 Series • M-153 Series, M-153S Blue, M-153S Red, M-153S Silver, M-153X Red, M-153X Silver, M-153XL Artic Bloom, M-153 XL Blue, M-153 XL Red • M210, M210S, M210X, M210XL, M250, M250A, M250B, M250E, M250ES, M250G, M250GS, M255-E, M255-ESB, M280, M280E, M285-E, M285-ESB • M320, M320S, M320X, M320XL, M325, M360, M360A, M360B, M360C • M460B, M460QS, M465-E, M465-ESB, M465-G • M680, M685, M685E, M685-E, M685-ESB • M-1408J, M-1410J, M-1411J, M-1412, M-1615, M-1617, M-1618, M-1618N, M-1618R, M-1619J, M-1622, M-1622H, M-1624, M-1625, M-1626, M-1628, M-1629, M-1630J, M-1631J, M-1632J • M-2000, M-2400, M-2404U, M-2408J, M-2409J, M-2410J, M-2410U, M-2414U, M-2421U, M-2623U, M-2624U, M-2625U, M-2626U • M-6205M, M-6206M, M-6207M, M-6305, M-6307, M-6308, M-6309, M-6312, M-6315, M-6316, M-6317, M-6318, M-6320, M-6322, M-6323, M-6324, M-6325, M-6332, M-6333, M-6334, M-6335, M-6337, M-6339U, M-6340U, M-6705, M-6750, M-6750H, M-6752, M-6755, M-6801D, M-6801M, M-6801MT, M-6802M, M-6803M, M-6804M, M-6805M, M-6806M, M-6807M, M-6808M, M-6809M, M-6810M, M-6811M, M-6812M, M-6813M, M-6814M, M-6815, M-6816, M-6817, M-6821B, M-6822, M-6823, M-6823A, M-6824, M-6825J, M-6826J, M-6827, M-6827J, M-6828B, M-6829B, M-6834, M-6839J, M-6840J, M-6841, M-6842J, M-6843, M-6844, M-6846, M-6847, M-6848, M-6849, M-6850FX, M-6851, M-6854M, M-6862, M-6864FX, M-6866, M-6867, M-6873B, M-6873H, M-6874H, M-6875B, M-6876B, M-6877B, M-6878, M-6878H, M-6879J, M-6880, M-6881 • M-7000, M-7301H, M-7301U, M-7309H, M-7315U, M-7317U, M-7325U, M-7328U, M-73305U, M-7333U, M-7334U, M-7810J, M-7818U • ML3109, ML3706, ML6226b, ML6228, ML6228h, ML6720, ML6721, ML6725 • MP8708, MP8709 • MT3418, MT3419, MT3421, MT3422, MT3423, MT3707, MT3707b, MT6224j, MT6225j, MT6451, MT6452, MT6456, MT6457, MT6459, MT6704, MT6704h, MT6705, MT6706, MT6707, MT6708, MT6709, MT6709h, MT6711, MT6723, MT6728, MT6821, MT6828, MT6828h, MT6830, MT6831, MT6832b, MT6833b, MT6834b, MT6835j, MT6839b, MT6840, MT6841, MT6916 • MX1023, MX1023h, MX1025, MX1026, MX1027, MX3042, MX3044, MX3044h, MX3103b, MX3142m, MX3143m, MX3210, MX3212, MX3215, MX3228, MX3231, MX3410, MX3410h, MX3412, MX3412h, MX3414, MX3416, MX3417, MX3558, MX3558h, MX3560, MX3560h, MX3562, MX3563, MX3563h, MX3610, MX3701, MX3702, MX6025, MX6025h, MX6027, MX6027h, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124h, MX6128, MX6131, MX6135, MX6211b, MX6214, MX6215b, MX6216, MX6420, MX6421, MX6422, MX6423, MX6424, MX6425, MX6426, MX6427, MX6428, MX6430, MX6431, MX6433, MX6436, MX6437, MX6438, MX6439, MX6440, MX6441, MX6442, MX6444, MX6444h, MX6445, MX6446, MX6447, MX6448, MX6450, MX6453, MX6454, MX6455, MX6625, MX6627, MX6627h, MX6629, MX6629h, MX6631, MX6633, MX6633h, MX6641, MX6650, MX6650h, MX6708, MX6708h, MX6710, MX6750, MX6912, MX6919, MX6920, MX6920h, MX6921b, MX6922b, MX6923b, MX6926b, MX6927, MX6928, MX6930, MX6931, MX6946m, MX6947m, MX6951, MX6955, MX6956, MX6957, MX6958, MX6959, MX6960, MX6961, MX6961h, MX7118,

> GATEWAY

Tip	Model Name / Number
41	MX7337, MX7337h, MX7340, MX7515h, MX7520h, MX8520, MX8710, MX8711, MX8715, MX8734, MX8736j, MX8738 • NX100X, NX200S, NX200X, NX250X, NX260X, NX270S, NX500S, NX500X, NX510, NX550X, NX550XL, NX560X, NX560XL, NX570, NX570S, NX570X, NX850X, NX850XL, NX860, NX860S, NX860X, NX860XL • P-170L, P-170X, P-171S, P-171SFX, P-171X, P-171XL, P-172SFX, P-172X, P-172XLFX, P-173XL, P-6301, P-6302, P-6311, P-6312, P-6313, P-6313H, P-6317, P-6318U, P-6822 • S-7110M, S-7125C, S-7200C, S-7200N, S-7210M, S-7220M, S-7225C, S-7310M, S-7320M, S-7500N, S-7510N, S-7700N, S-7710M, S-7710N, • Solo 1100, Solo 1150, Solo 1200, Solo 1400, Solo 1450, Solo 600YG2, Solo 600YGR • T-140X, T-1602M, T-1603M, T-1604M, T-1605M, T-1616, T-1620, T-1621, T-1622, T-1623, T-1625, T-1628, T-1628H, T-1629, T-1630, T-1631, T-6208C, T-6303C, T-6304C, T-6305C, T-6307C, T-6308C, T-6311, T-6313, T-6313H, T-6315C, T-6316C, T-6317C, T-6318C, T-6319C, T-6320C, T-6321, T-6322C, T-6324C, T-6325C, T-6326C, T-6327C, T-6330U, T-6801M, T-6815, T-6815h, T-6816h, T-6818C, T-6819C, T-6820C, T-6821C, T-6822C, T-6825C, T-6826C, T-6827C, T-6828, T-6829, T-6829H, T-6830C, T-6831C, T-6832C, T-6834C, T-6836, T-6840C, T-6841H, T-6842, T-6842H

HEWLETT PACKARD

Tip	Model Name / Number
5	• G6000, G7000 • L2105 • Mobile Workstation NW8000 • Special Edition: L2000(LiveStrong), L2000series, L2005, L2098, L2099, L2105, L2205 • Tablet PC: TC1100, TC4200
41	• Deskjet 450 • OfficeJet R45 • OmniBook: 500, 900, 2100, 2103, 2104, 2105, 2106, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 3000, 3100, 3101, 3102, 3250, 4100, 4101, 4102, 4103, 4104, 4105, 4106, 4107, 4108, 4110, 4111, 4150, 6000, 6100, 7000, 7100, 7150, 2100 series, 3000CTX, 4150B, 500B, 6000B, 6000C, 6000 series, 7103T, XE, XE2, XE2-DA, XE2-DB, XE2-DC, XE2-DD, XE2-DE, XE2-DI, XE3, XE3L, XE4100, XE4400, XE4500, XE-DA, XT1000, XT6200
55	• G60-125NR • HDXX16-1000, HDX16t • Tablet PC: TC4400

HEWLETT PACKARD BUSINESS NOTEBOOK

Tip	Model Name / Number
5	• NC4000, NC4010, NC4200, NC6000, NC6120, NC6125, NC6200, NC6220, NC6230, NC6325, • NC8000, NC8200, NC8230 • NW8000, NW8200, NW8240, NX4800, NX4820, NX5000, NX6110, NX6120, NX6125, NX6130, • NX7000 series, NX7000, NX7010, NX7100, NX7300, NX8200, NX8220, NX9020, NX9030

> HEWLETT PACKARD BUSINESS NOTEBOOK

Tip	Model Name / Number
41	• N1050V • NX9000 series, NX9000, NX9005, NX9010
55	• 6510b, 6515b, 6710b, 6710s, 6715b, 6715s, 6730S, 6910p • NC2400, NC4400, NC6110, NC6140, NC6320, NC6400, NC8430 • NW8440, NW9440 • NX6115, NX6310, NX6315, NX6320, NX6325, NX6330, NX7400, NX8410, NX8420, NX9420

HEWLETT PACKARD PAVILION

Tip	Model Name / Number
5	• DV1000 series, DV1000, DV1000T, DV1010CA, DV1010CAF, DV1010US, DV1040CA, DV1040US, DV1130, DV1133, DV1150US, DV1207, DV1217, DV1220, DV1227, DV1240, DV1240US, DV1310, DV1311, DV1321, DV1331, DV1340, DV1410, DV1411, DV1420, DV1510, DV1520US, DV1530US, DV1540US, DV1580, DV1622NR, DV1629US, DV1648US, DV1650US, DV1657CL, DV1658US, DV1659US, DV1660CA, DV1680US • DV2000, DV2000T, DV2000Z, DV2001tu, DV2001tx, DV2002TU, DV2002tx, DV2003ea, DV2003tu, DV2003tx, DV2004ea, DV2004tu, DV2004tx, DV2004xx, DV2005ea, DV2005tu, DV2005tx, DV2005XX, DV2006ea, DV2006tu, DV2006tx, DV2006XX, DV2007ea, DV2007tx, DV2008ea, DV2008tu, DV2009xx, DV2011tx, DV2011xx, DV2012TX, DV2013tu, DV2013TX, DV2015NR, DV2020CA, DV2020ea, DV2020US, DV2023TU, DV2023TX, DV2024tx, DV2025LA, DV2025NR, DV2025TU, DV2028ea, DV2029ea, DV2030ea, DV2031ea, DV2031tu, DV2032ea, DV2033ea, DV2034ea, DV2035ea, DV2035LA, DV2035US, DV2036ea, DV2037US, DV2040CA, DV2040US, DV2046TU, DV2047CL, DV2049tx, DV2050US, DV2053ea, DV2064ea, DV2065ea • DV2100 series, DV2101au, DV2101tx, DV2101xx, DV2102eu, DV2102tx, DV2103ea, DV2103tx, DV2104au, DV2104eu, DV2104tu, DV2104tx, DV2105xx, DV2106ea, DV2106eu, DV2108ea, DV2109nr, DV2109tu, DV2110RS, DV2110tu, DV2110tx, DV2111tx, DV2112tx, DV2113tu, DV2113TX, DV2114tx, DV2115ea, DV2115tu, DV2115tx, DV2116ea, DV2116tx, DV2116WM, DV2117TX, DV2118la, DV2118tx, DV2119tx, DV2120CA, DV2120la, DV2120tu, DV2120US, DV2121tu, DV2121tx, DV2122tu, DV2122tx, DV2123tx, DV2124tu, DV2124tx, DV2125ea, DV2125la, DV2125NR, DV2125tx, DV2125US, DV2126ea, DV2126tu, DV2126tx, DV2127tx, DV2128tx, DV2129ea, DV2129us, DV2130ea, DV2130la, DV2130tx, DV2130US, DV2131ea, DV2131tx, DV2132ea, DV2132tx, DV2133ea, DV2133tx, DV2134ea, DV2134tx, DV2134us, DV2135br, DV2135la, DV2137tx, DV2138tx, DV2138XX, DV2139tx, DV2140la, DV2140tx, DV2141tx, DV2144tx, DV2145br, DV2145tx, DV2146tx, DV2147ea, DV2147tx, DV2148tx, DV2149ea, DV2149tx, DV2150ea, DV2150tx, DV2151ea, DV2151tx, DV2152ea, DV2152tx, DV2153tx, DV2154tx, DV2155tx, DV2156tx, DV2157tx, DV2160la, DV2161tx, DV2171CA, DV2171CL, DV2172ea, DV2173ea, DV2174CL, DV2174ea, DV2175ea, DV2184ea, DV2185ea, DV2188ea, DV2190ea, DV2196ea, DV2197ea • DV2200 series, DV2200CTO, DV2201ca, DV2201tx, DV2201xx, DV2202ca, DV2202tu, DV2202tx, DV2203au, DV2207tx, DV2208tx, DV2209tx, DV2210US, DV2211tx, DV2213ca, DV2213cl, DV2213-tu, DV2214US, DV2225NR, DV2310US, DV2312, DV2315NR, DV2415, DV2416US, DV2418NR, DV2419US, DV2420, DV2610US, DV2615US, DV2620US, DV2660SE, DV2700 series, DV2710CA, DV2710US, DV2715, DV2715NR, DV2718US, DV2719, DV2745SE, DV2807NR, DV2810US, DV2815NR, DV2845SE, DV2910US, DV2911US, DV2915NR, DV2940SE, DV2945SE • DV4000 series, DV4030US, DV4040, DV4130, DV4150, DV4170, DV4217CL, DV4230, DV4250, DV4269, DV4275, DV4305US, DV4307, DV4335

> HEWLETT PACKARD PAVILION

Tip	Model Name / Number
5	• DV5000 series, DV5000T, DV5000Z, DV5020, DV5030, DV5035, DV5115NR, DV5116NR, DV5117CA, DV5120US, DV5129US, DV5130US, DV5135NR, DV5139US, DV5140US, DV5150US, DV5163CL, DV5170US, DV5178US, DV5190US, DV5215US, DV5216CA, DV5220US, DV5230US, DV5237CL, DV5250US • DV6000 series • DV6100 series, DV6205US, DV6215US, DV6225US, DV6226, DV6233SE, DV6235NR, DV6244US, DV6245US, DV6258SE • DV6300 series, DV6305US, DV6308NR, DV6324US, DV6326US, DV6338SE, DV6345US, DV6358SE, DV6405US, DV6406NR, DV6408NR, DV6409US, DV6415US, DV6426US, DV6436NR, DV6445US, DV6450US, DV6458SE, DV6565US • DV6600 series, DV6604NR, DV6626US, DV6628US, DV6633US, DV6648SE, DV6654US, DV6662SE, DV6700T, DV6704, DV6704NR, DV6707US, DV6736, DV6736NR, DV6807US, DV6810US, DV6812NR, DV6815NR, DV6830US, DV6833US, DV6835NR, DV6875SE, DV6885SE, DV6910US, DV6911US, DV6915NR, DV6920US, DV6928US, DV6985SE • DV8000, DV8000T, DV8000Z, DV8110, DV8113, DV8120US, DV8125, DV8130US, DV8135, DV8210US, DV8220US, DV8225NR, DV8230US, DV8233CL, DV8235NR, DV8280US, DV8309US, DV8320US, DV8327CA, DV8380US • DV9700T, DV9715NR, DV9720US, DV9730, DV9810US, DV9812US, DV9815NR, DV9825NR, DV9910US, DV9925NR • tx1000 series, tx1001xx, tx1002au, tx1002xx, tx1003xx, tx1004au, tx1005au, tx1020ea, tx1040ea • tx1100 series, tx1110us, tx1115nr, tx1119us • tx1200 series, tx1205us, tx1210us, tx1212nr, tx1215nr, tx1220us • tx1300 series, tx1305us, tx1308nr, tx1320us • tx1400 series, tx1410US • tx2000 series, tx2000z, TX2110US, TX2510US, TX2525NR, • ZE2000 series, ZE2000, ZE2002AP, ZE2108, ZE2113, ZE2117US, ZE2308WM, ZE2315, ZE2401, • ZE4900, ZE4901US, ZE4904US, ZE4906US, ZE4907, ZE4908US, ZE4910CA, ZE4910US, ZE4911US, ZE4930, ZE4947 • ZT3000 series, ZT3000, ZT3010US, ZT3280US, ZT3350US, ZT3380US • ZT4000 series, ZT4000
28	• DV2514TX, DV2742SE, DV2990NR • DV4420US • DV6000, DV6000t, DV6000z, DV6040CA, DV6040US, DV6045NR, DV6058, DV6058CL, DV6102OD, DV6103, DV6103NR, DV6105CA, DV6105US, DV6107US, DV6108NR, DV6109OM, DV6110CA, DV6110TX, DV6110US, DV6113US, DV6114TX, DV6115CA, DV6119US, DV6120, DV6120CA, DV6120US, DV6125OM, DV6128OD, DV6129US, DV6130CA, DV6130US, DV6131OD, DV6135CA, DV6135NR, DV6139US, DV6140CA, DV6140US, DV6149US, DV6150CA, DV6150US, DV6165CL, DV6171CL, DV6174CA, DV6174CL, DV6195XX, DV6255, DV6265, DV6568SE, DV6575US, DV6589US, DV6672US, DV6675US, DV6748US, DV6768, DV6768SE, DV6775US, DV6780, DV6780SE • DV9000 series, DV9000z, DV9001XX, DV9005CA, DV9005US, DV9006TX, DV9007TX, DV9008EA, DV9008NR, DV9009, DV9009CA, DV9009CL, DV9009NR, DV9009US, DV9010, DV9010CA, DV9010US, DV9011TX, DV9013CA, DV9013CL, DV9014TX, DV9015, DV9016, DV9017, DV9018TX, DV9019, DV9020, DV9021TX, DV9022TX, DV9024EA, DV9030US, DV9033US, DV9035NR, DV9040US, DV9060US, DV9074CL, DV9095EA • DV9100 series

> HEWLETT PACKARD PAVILION

Tip	Model Name / Number
28	• DV9200 series, DV9200, DV9205US, DV9207US, DV9208NR, DV9210US, DV9220US, DV9230US, DV9235NR, DV9260NR, DV9260US, DV9308NR, DV9310US, DV9335NR, DV9408NR, DV9410US, DV9420US, DV9428 • DV9500 series, DV9525US, DV9535US, DV9540US • DV9600 series, DV9608NR, DV9620ED, DV9620NR, DV9620US, DV9628NR, DV9640US, DV9650US
41	• 6000 • N3000 series, N3100, N3110, N3150, N3190, N3210, N3215, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3390 • N3400 series, N3402, N3410, N3438, N3478, N3490, N5000 • N5100 series, N5125, N5130, N5150, N5170, N5190, N5195, N5200 series, N5210, N5210M, N5240, N5250, N5270, N5290, N5295 • N5300 series, N5310, N5340, N5350, N5390 • N5400 series, N5415, N5420L, N5421L, N5425, N5430, N5435, N5440, N5441, N5445, N5450, N5451, N5455, N5470, N5474, N5475, N5490, N5491, N5495 • N5500 series, N5511L, N5584 • N6000 series, N6100, N6195, • XF series, XF145, XF255, XF328, XF335 • XH series, XH35, XH156, XH176, XH215, XH226, XH260, XH365, XH395, XH455, XH485, XH555, XH675 • XT series, XT118, XT155, XT236, XT276, XT375, XT412, XT537QV, XT545, XT595, XT1135, XT4345QV, XT5300, XT5366WM, XT5477WM • XZ series, XZ168, XZ185, XZ275, XZ295, XZ355 • ZE1000 series, ZE1000, ZE1110, ZE1115, ZE1210, ZE1220, ZE1230, ZE1250, • ZE4000 series • ZE4100 series, ZE4100, ZE4115, ZE4125, ZE4145 • ZE4200 series, ZE4210, ZE4220, ZE4230, ZE4236, ZE4239, ZE4240 • ZE4300 series, ZE4300, ZE4315CA, ZE4315US, ZE4325CA, ZE4325US, ZE4335US, ZE4365US, • ZE4400 series, ZE4400, ZE4401, ZE4402, ZE4420, ZE4427, ZE4430, ZE4455EA, ZE4510, ZE4530US, ZE4540US, ZE4547, ZE4560US, ZE4610US, ZE4630US, ZE4805US • ZE5000 series, ZE5000, ZE5155, ZE5165, ZE5170, ZE5185, ZE5200, ZE5279, ZE5300, ZE5366, ZE5375US, ZE5385US, ZE5395US, ZE5470US, ZE5475CA, ZE5475F, ZE5478CL, ZE5490US, ZE5560, ZE5570US, ZE5580US, ZE5602, ZE5604RS, ZE5607WM, ZE5615SR, ZE5620US, ZE5630US, ZE5700, ZE5715CA, ZE5720US, ZE5730US, ZE5738RS • ZT series, ZT1000, ZT1114, ZT1121s, ZT1125, ZT1130, ZT1131s, ZT1135, ZT1141, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1175, ZT1180, ZT1185, ZT1190, ZT1195 • ZT1200 series, ZT1201, ZT1230, ZT1250, ZT1260, ZT1270, ZT1290
55	• DV4T, DV4Z, DV4-1007ef, DV4-1125nr, DV4-1145GO, DV4-1155SE, DV1010ep, DV1042tx • DV5/CT, DV5-1000, DV5-1000ea, DV5-1001au, DV5-1001ax, DV5-1001tx, DV5-1002au, DV5-1002ax, DV5-1002nr, DV5-1002us, DV5-1003ax, DV5-1003nr, DV5-1003tx, DV5-1004ax, DV5-1004nr, DV5-1004tx, DV5-1005ax, DV5-1005ef, DV5-1005eg, DV5-1005em, DV5-1005tx, DV5-1006ax, DV5-1006tx, DV5-1007ax, DV5-1007ef, DV5-1008ea, DV5-1008tx, DV5-1009ax, DV5-1009ea, DV5-1009tx, DV5-1010ea, DV5-1010ef, DV5-1010eg, DV5-1010et, DV5-1010tx, DV5-1011ea, DV5-1011tx, DV5-1012ea, DV5-1012tx, DV5-1013tx, DV5-1014tx, DV5-1015ea,

> HEWLETT PACKARD PAVILION

Tip	Model Name / Number
55	• DV5-1015tx, DV5-1016tx, DV5-1017nr, DV5-1017tx, DV5-1018tx, DV5-1019tx, DV5-1020ef, DV5-1020et, DV5-1020tx, DV5-1021tx, DV5-1022el, DV5-1022tx, DV5-1023tx, DV5-1024el, DV5-1024tx, DV5-1025tx, DV5-1026tx, DV5-1027tx, DV5-1028ca, DV5-1028tx, DV5-1029tx, DV5-1030ef, DV5-1030el, DV5-1030ep, DV5-1030es, DV5-1030tx, DV5-1031tx, DV5-1032el, DV5-1032tx, DV5-1033tx, DV5-1034el, DV5-1034tx, DV5-1035tx, DV5-1036tx, DV5-1037tx, DV5-1038tx, DV5-1039tx, DV5-10403ep, DV5-1040ec, DV5-1040ee, DV5-1040eg, DV5-1040eh, DV5-1040er, DV5-1040et, DV5-1040ew, DV5-1040ez, DV5-1040tx, DV5-1041tx, DV5-1043tx, DV5-1044ca, DV5-1044tx, DV5-1045tx, DV5-1046tx, DV5-1048er, DV5-1050ei, DV5-1050ek, DV5-1050er, DV5-1050es, DV5-1060ec, DV5-1060ee, DV5-1060ew, DV5-1070ec, DV5-1070ee, DV5-1070er, DV5-1070es, DV5-1070ew, DV5-1080eh, DV5-1080ei, DV5-1080el, DV5-1087eo, DV5-1090es, DV5-1094eo, DV5-1094xx, DV5-1095eo, DV5-1096xx, DV5-1098xx, DV5-1099xx, DV5-1100, DV5-1125nr, DV5-1157CA • DV5t-1000 • DV5z-1000 • DV7/CT, DV7-1000ea, DV7-1000ef, DV7-1000eg, DV7-1001ea, DV7-1001ef, DV7-1001eg, DV7-1001tx, DV7-1001xx, DV7-1002ea, DV7-1002tx, DV7-1002xx, DV7-1003ea, DV7-1003el, DV7-1003eo, DV7-1003tx, DV7-1003xx, DV7-1004ea, DV7-1004tx, DV7-1005ef, DV7-1005eg, DV7-1005eo, DV7-1005es, DV7-1005tx, DV7-1006tx, DV7-1007tx, DV7-1008ef, DV7-1008eg, DV7-1008tx, DV7-1009tx, DV7-1010ed, DV7-1010ef, DV7-1010eg, DV7-1010el, DV7-1010eo, DV7-1010es, DV7-1010et, DV7-1010tx, DV7-1011tx, DV7-1012tx, DV7-1013tx, DV7-1014ca, DV7-1014tx, DV7-1015eg, DV7-1015el, DV7-1015eo, DV7-1015tx, DV7-1016nr, DV7-1016tx, DV7-1017eo, DV7-1017tx, DV7-1018eg, DV7-1018tx, DV7-1019tx, DV7-1020ea, DV7-1020eg, DV7-1020el, DV7-1020eo, DV7-1020es, DV7-1020ev, DV7-1020ew, DV7-1020tx, DV7-1020us, DV7-1021tx, DV7-1022tx, DV7-1023cl, DV7-1023em, DV7-1023tx, DV7-1024el, DV7-1024tx, DV7-1025eg, DV7-1025NR, DV7-1025tx, DV7-1026tx, DV7-1027ca, DV7-1027tx, DV7-1029eg, DV7-1029tx, DV7-1030eb, DV7-1030ef, DV7-1030eg, DV7-1030el, DV7-1030en, DV7-1030eo, DV7-1030ep, DV7-1030es, DV7-1030ev, DV7-1030tx, DV7-1031tx, DV7-1032tx, DV7-1033tx, DV7-1034ca, DV7-1034tx, DV7-1035ef, DV7-1035em, DV7-1035eo, DV7-1035es, DV7-1038ca, DV7-1040ec, DV7-1040ef, DV7-1040em, DV7-1040eo, DV7-1040es, DV7-1040et, DV7-1040ew, DV7-1045eg, DV7-1045tx, DV7-1048ez, DV7-1050ea, DV7-1050eb, DV7-1050ed, DV7-1050ef, DV7-1050eg, DV7-1050eo, DV7-1050er, DV7-1051xx, DV7-1052xx, DV7-1053ez, DV7-1053xx, DV7-1055ea, DV7-1060ec, DV7-1060ef, DV7-1060eg, DV7-1060el, DV7-1060em, DV7-1060en, DV7-1060eo, DV7-1060ep, DV7-1060ew, DV7-1060ez, DV7-1065ef, DV7-1067ef, DV7-1070eb, DV7-1070ed, DV7-1070ee, DV7-1070ef, DV7-1070eg, DV7-1070ei, DV7-1070ek, DV7-1070el, DV7-1070eo, DV7-1070ev, DV7-1075la, DV7-1080ed, DV7-1080el, DV7-1080eo, DV7-1080es, DV7-1080ew, DV7-1080ez, DV7-1090eb, DV7-1090ed, DV7-1090en, DV7-1090eo, DV7-1090er, DV7-1092eo, DV7-1093eo, DV7-1094eo, DV7-1095eo, DV7-1098eo, DV7-1099ef, DV7-1123ca, DV7-1128ca, DV7-1130us, DV7-1135NR, DV7-1150us, DV7-1153ca, DV7-1157NR, DV7-1170us, DV7-1174ca, DV7-1177ca • DV7t, DV7t-1000 • DV7z, DV7z-1000 • G50-104NR, G50-109NR • G60-120US, G60-125NR, G60-127NR

IBM

Tip	Model Name / Number
9	• Netfinity7000M10
49	• PS/Note425

IBM THINKPAD

Tip	Model Name / Number
9	• 240 series, 240, 240X, 240Z • 365, 365C, 365CD, 365CS, 365CSD, 365E, 365ED, 365X, 365XD • 380 series, 380, 380D, 380D-MMX, 380E, 380ED, 380XD, 380XD (Type2635-Exx), 380Z (Type2635-Bxx), 380Z (Type2635-Hxx), 380Z(Type2635-Jxx), 385, 385CD, 385D, 385D-MMX, 385ED, 385XD, 385XD(Type2635-Dxx), 390, 390E, 390X • 535, 550, 560, 560C, 560E, 560X, 560Z, 570, 570E • 600, 600A, 600E, 600X • 701, 770, 701C, 701CS, 770E, 770ED, 770X, 770Z • A20 series, A20, A20M, A20P, A21, A21e, A21M, A21P, A22e, A22M, A22P • A30 series, A30, A30P, A31, A31P • E530 • i1200 series, i1200, i1210, i1211, i1241, i1251, i1271, i1300, i13001171-NMU • i1300 series, i1321, i1340, i1351, i1361, i1391, i1400, i1418, i1420, i1421, i1441, i1442, i1460, i1480, i1482, i1500, i1700, i1720, i1721 • R30, R31, R32 • R40 series, R40, R40e, R50, R50 series, R50e, R50p, R51, R52 • S • T20 series, T20, T21, T22, T23 • T30 series, T30, T40 • T40 series, T41, T41p, T42, T42p, T43, T51 • X20 series, X20, X21, X22, X23, X24 • X30 series, X30, X31, X40, X41Tablet
49	• 350, 350C

LENOVO

Tip	Model Name / Number
44	• 3000C100, 3000C200, 3000N100, 3000V100, 3000V200

LENOVO THINKPAD

Tip	Model Name / Number
5	• R51e, R52 • X41 Tablet
44	• R60e0656, R60e0657, R60e0658, R60e0659, R60e9444, R60e9445, R60e9446, R60e9447, R60e9455, R60e9456, R60e9457, R60e9458, R60e9459, R60e9460, R60e9461, R60e9462, R60e9463, R60e9464

LENOVO THINKPAD

Tip	Model Name / Number
44	• R61 (14.1 inch wide screen), R617732, R617733, R617734, R617735, R617736, R617737, R617742, R617743, R617744, R617751, R617753, R617754, R617755, R618914, R618918, R618932, R618942, R618943 • R61e (15.4" wide screen), R61e7649, R61e7650, • R61i Series (14.1" wide screen), R61i (14.1" & 15" Standard Screen), R61i (15.4" wide screen), R61i7650, R61i7732, R61i7742, R61i8918, R61i8932, R61i8943 • R500 • R4007443 • R600656, R600657, R600658, R600659, R609444, R609445, R609446, R609447, R609455, R609456, R609457, R609458, R609459, R609460, R609461, R609462, R609463, R609464 • T60p1951, T60p1952, T60p1953, T60p1954, T60p1955, T60p1956, T60p2007, T60p2008, T60p2009, T60p2613, T60p2623, T60p2637 • T61p (14.1 inch wide screen), T61p6459, T61p6460, T61p8889, T61p8891 • T500 • T4002764, T4007417 • T601951, T601952, T601953, T601954, T601955, T601956, T602007, T602008, T602009, T602613, T602623, T606369, T606371, T606372, T608741, T608743, T608744, T611959, T616377, T616378, T616379, T616457, T616460, T616466, T616480, T616481, T617658, T617659, T617660, T617661, T617662, T617663, T617664, T617665, T618889, T618891, T618895, T618897, T618898 • X60, X60 Tablet PC 6363, X60 Tablet PC 6364, X60 Tablet PC 6365, X60 Tablet PC 6366, X60 Tablet PC 6367, X60 Tablet PC 6368, X60s, X61 Tablet PC 7762, X61 Tablet PC 7764, X61 Tablet PC 7767 • Z60m2529, Z60m2530, Z60m2531, Z60t, Z61e0672, Z61e0673, Z61e0674, Z61e9450, Z61e9451, Z61e9452, Z61e9453, Z61m0672, Z61m0673, Z61m0674, Z61m2532, Z61m9450, Z61m9451, Z61m9452, Z61m9453, Z61p0672, Z61p0673, Z61p0674, Z61p9450, Z61p9451, Z61p9452, Z61p9453, Z61t

PACKARD BELL

Tip	Model Name / Number
3	• Easy One • EasyNote: 3705, SC

PANASONIC

Tip	Model Name / Number
3	• CF-V21, CF-V21P • ToughBook: 21, V21
9	• ToughBook: 18, 51, 73, P1, T2, W4, Y2, Y4

SONY

Tip	Model Name / Number
3	• VAIO All-in-One FX Series • SDM-M51

SONY VAIO PCG

Tip	Model Name / Number
3	• 6G4L, • 700 series, 705, 705C, 707, 711, 717, 719, 729, 731, 735, 737, 745, 747, 748 • 800 series, 808, 812, 818, 838 • 900 series, 933A, 945A, 954A, 955A, 961A, 962A, 974L • 9201, 9231, 9401, 9411, 9830 • F series, F150, F160, F180, F190, F200, F250, F270, F280, F290, F305, F340, F350, F360, F370, F390, F400, F403, F420, F430, F450, F480, F480K, F490, F490K, F520, F540, F560, F560K, F570, F580, F580K, F590, F610, F630, F640, F650, F650K, F676, F680, F690, F807K, F808K, F809K • FR102, FR215E, FR215H, FR215M, FR215S, FR33/B, FR55/B, FR77E/B • FX series, FX120, FX120K, FX140, FX150, FX150K, FX170, FX190, FX190K, FX200, FX200K, FX201, FX210, FX215, FX220, FX240, FX250, FX270, FX290K, FX310, FX310K, FX340, FX370, FX390, FX55G/BP, FX776, FX876, FX902P, FX905P • FXA series, FXA32, FXA33, FXA35, FXA36, FXA47, FXA48, FXA49, FXA53, FXA59, FXA63 • GR315MP • GRS series • GRS100 series, GRS100, GRS150, GRS150K, GRS150P, GRS170, GRS170P, GRS175, GRS515M, GRS515SP/R, GRS55/B, GRS614MK, GRS614MP, GRS615SK, GRS615SP, GRS700K • GRV516G, GRV550, GRV616G, GRV616S, GRV670, GRV670P, GRV680, GRV680P, GRV88G • GRX series, GRX316MP, GRX316SP, GRX415MP, GRX416SP • GRX500 series, GRX500, GRX501, GRX510, GRX510K, GRX510P, GRX515G, GRX516MD, GRX516SP, GRX520, GRX520K, GRX520P, GRX530, GRX530K, GRX530P, GRX550, GRX550K, GRX550P, GRX560, GRX560K, GRX560P, GRX570, GRX570K, GRX570P, GRX580, GRX580K, GRX580P, GRX590, GRX590K, GRX590P, GRX590R, GRX590RP • GRX600 series, GRX600, GRX606, GRX615G, GRX615S, GRX616MK, GRX616MP, GRX616SP, GRX626, GRX626P, GRX650, GRX650P, GRX670, GRX670K, GRX670P, GRX690, GRX690K, GRX690P • GRX700 series, GRX707, GRX727 • GRZ series, GRZ515G, GRZ530 • GRZ600 series, GRZ600P1, GRZ600P3, GRZ600P6, GRZ610, GRZ615G, GRZ615S, GRZ630, GRZ660, GRZ77/B, GRZ77E/P • NV series, NV55E/B • NV100 series, NV100, NV105, NV109M, NV170, NV170P, NV190, NV190P • NV200 series, NV200, NV209, NV290 • NVR23 • R505 series, R505BF, R505D, R505DCP, R505DF, R505DFK, R505DFP, R505DL, R505DLK, R505DLP, R505DS, R505DSK, R505DSP, R505Dx, R505E, R505EC, R505ECK, R505ECP, R505EL R505ELK, R505ELP, R505ES, R505ESK, R505ESP, R505Ex, R505G, R505GC, R505GCK, R505GCP, R505GL, R505GLK, R505GLP, R505JL, R505MF, R505TE, R505TEK, R505TF, R505TL, R505TS, R505TSK • XG series, XG18, XG19, XG28, XG29, XG38, XG38K, XG39, XG39K, XG500, XG500K, XG700, XG700K, XG9 • XR9 • Z505 series, Z505 SuperSlim, Z505FA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505S Pro, Z505SX,

SONY VAIO VGN

Tip	Model Name / Number
3	• A50B, A230, A230P CTO, A240, A240P CTO, A250, A270, A270P CTO, A600, A690, • AR130G, AR150G, AR170GU1, AR170PU2, AR190, AR190G, AR230G, AR250G, AR270, AR290G, AR320E, AR350E, AR370, AR370 with Blu-ray Disc, AR390E, AR520E, AR550E, AR550U, AR570 CTO, AR570 with Blu-ray, AR590E, AR610E, AR620E, AR630E, AR660U, AR670, AR670N1, AR670N2, AR670N3, AR690U, AR750E/B, AR830E, AR850E, AR890U • AX570G, AX580G • BX4AANS, BX4AAPS, BX4KANB • BX6AANS, BX6AAPS • BX90PS, BX90S, BX94PS, BX96PS • BX540 with WAN, BX540B, BX541B, BX543B, BX546B, BX560B, BX570B • BX640P20, BX640P47, BX640P48, BX640P49, BX640P52, BX660P23, BX660P26, BX660P46, BX660P49, BX660P51, BX660P53, BX660PS2, BX670B BTO, BX670P41, BX670P42, BX670P43, BX670P44, BX670P45, BX670P46, BX670P47, BX670P48, BX670P51, BX670P52, BX670P53, BX670P54, BX670P55, BX670P56, BX670P57, BX675P • BX740N1, BX740N2, BX740N3, BX740N4, BX740NS4, BX740NS5, BX740NS6, BX740NSA, BX740NW1, BX740NW2, BX740P1, BX740P2, BX740P4, BX740PS4, BX740PS5, BX740PS6, BX740PSA, BX740PW1, BX740PW2, BX760N1, BX760N2, BX760N3, BX760N4, BX760N5, BX760NS4, BX760NS5, BX760NS6, BX760NSA, BX760P1, BX760P2, BX760P3, BX760P4, BX760P5, BX760PS4, BX760PS5, BX760PS6, BX760PSA • C50HA/W, C50HB/W, C51HA/W, C51HB/W, C60HB/G, C60HB/H, C60HB/L, C60HB/P, C61HB/G, C61HB/H, C61HB/L, C61HB/P, C70B/W, C71B/W, C90HS, C90NS, C90S, C140G/B, C150P/B, C190, C190P/H, C210E/H, C220E/H, C2291NW/H, C240E/B, C250N/B, C290, C290 Graphic Splash Edition, C291NW/H • CR115E/P, CR120E/L, CR120E/P, CR120E/R, CR125E/B, CR131E/L, CR140E/B, CR150E/B, CR220E/L, CR220E/N, CR220E/P, CR220E/R, CR220E/W, CR240E/B, CR240N/B, CR290E1, CR290E2, CR290E3, CR290E4, CR290EAL, CR290EAN, CR290EAP, CR290EAR, CR290EAW, CR320E, CR320E/N, CR510E/P, CR520E, CR520E/W • CS110E, CS110E/R, CS110E/W, CS118E/P, CS118E/Q, CS118E/R, CS118E/W, CS190NAB, CS190NAC, CS190NAD, CS190NBB, CS190NCA, CS190NCB, CS190NCC • E series, E50B/B, E50B/D, E50B/S, E51B/D, E51B/S, E70B/B, E70B/S, E71B/S, E81B/B, E91B/B • F170P/B, F830/W • FE series, FE20, FE21/W, FE30B, FE31B/W, FE32B/W, FE32H/W, FE32HA/W, FE32HB/W, FE33B/W, FE33H/W, FE33HB/W, FE41, FE41E, FE41S, FE41Z, FE50B, FE51B/H, FE52B/H, FE53B/W, FE53HB/W,FE90PS, FE90S, FE91PS, FE91S, FE92HS, FE92NS, FE92S, FE550G, FE570G, FE590, FE590GC, FE590PA, FE590PB, FE650G, FE660, FE670G, FE690GB, FE690PB, FE770G, FE790GN, FE790PL, FE870E/H, FE880E/H, FE890, FE890 Graphic Splash Edition, FE890N/H • FJ10B, FJ11/W, FJ11B/W, FJ12/W, FJ12B/W, FJ21B/G, FJ21B/L, FJ21B/R, FJ22B/G, FJ22B/L, FJ22B/R, FJ57SP, FJ58SP, FJ90PS, FJ90S, FJ91PS, FJ91S, FJ92PS, FJ92S, FJ170/B, FJ180P/G, FJ180P/L, FJ180P/R, FJ180P/W, FJ270/B, FJ270P/B, FJ290, FJ290 CTO, FJ290P1/B, FJ290P1/G, FJ290P1/L, FJ290P1/R, FJ290P1/W • FS15GP, FS15SP, FS18GP, FS18SP, FS25GP, FS25SP, FS28GP, FS28SP, FS35SP, FS38SP, FS115B, FS115Z, FS500P12, FS520B, FS530B, FS540P, FS550, FS570, FS620, FS625B, FS625B/W, FS630/W, FS635B/W, FS640/W, FS645P/H, FS660/W, FS660P/W, FS675P/H, FS680/W,FS690, FS715, FS730/W, FS740/W, FS742/W, FS745P/H, FS750P/W, FS755P/H, FS760/W,

> SONY VAIO VGN

Tip	Model Name / Number
3	FS780/W, FS790, FS810/W, FS840, FS840/W, FS850P/W, FS875P/H, FS920, FS940, FS950, FS980, FS990, FS7901, FS8900, FS8900 CTO, FS8900M, FS8900P3, FS8900P4, FS8900P5, FS8900V • FW130E/W, FW130N/W, FW139E/H, FW139N/W, FW140E/H, FW140E/W, FW140N/W, FW145E/W, FW160E/H, FW170J/H, FW180E/H, FW198U/H, FW235J, FW270J, FW298Y • FZ11L, FZ11M, FZ11S, FZ11Z, FZ19VN, FZ50B, FZ70B, FZ90HS, FZ90NS, FZ90S, FZ130E/B, FZ140E/B, FZ140N/B, FZ145E/B, FZ150E, FZ150E/BC, FZ160E/B, FZ180E/B, FZ180U/B, FZ190, FZ190 with Blu-ray Disc, FZ190CTO, FZ190E/1, FZ190E/2, FZ210C/E, FZ230E/B, FZ240E/B, FZ240N/B, FZ250E/B, FZ260E/B, FZ280E/B, FZ285U/B, FZ290E1, FZ290N2, FZ290N3, FZ290N4, FZ290N5, FZ290N6, FZ410E/B, FZ430E/B, FZ470E/B, FZ480E/B, FZ485U/B, FZ490NAB, FZ490NBB, FZ490NCB, FZ490NDB, FZ490NFB • GRV7P, GRZ20S • N50HB, N51B, N51HB, N110G, N130G/W, N150G/W, N150P/B, N170G/T, N170G/W, N220E/B, N230E/B, N230E/T, N230E/W, N230N/B, N250E/B, N250E/W, N250N/B, N270E/T, N310FH, N320E, N320E/B, N320E/W, N325E/B, N325E/W, N350E/B, N350E/T, N350E/W, N365E/B, N395E/B, • NR110E/S, NR120E/S, NR140E/S, NR160E/S, NR160E/T, NR160E/W, NR160N/S, NR180E/S, NR180E/T, NR180E/W, NR180N/S, NR185E/S, NR185E/T, NR185E/W, NR185N/S, NR220E/S, NR260E/S, NR260E/W, NR310E/S, NR385S/E, NR420E/L, NR430E/L, NR430E/P, NR475N/S, NR480E/S, NR485E/L, NR485E/S, NR485E/T, NR485E/W, NR498E/L, NR498E/S • S38GP, S46GP, S48GP, S53B/S, S54B/S, S55B/S, S55SP/S, S72PB/B, S73PB/B, S92PS/S, S92PSY, S92S/S, S93PS/S, S93PSY, S93S/S, S94PS, S94S, S380, S380B Professional, S430P/S, S460/B, S460P/B, S470P/S, S480, S560P/B, S570P/S, S57SP/B, S580 • SR130E/B, SR130E/P, SR130E/S, SR130N/B, SR140E/B, SR140E/P, SR140E/S, SR140N/S, SR165E/B, SR165E/P, SR165E/S, SR165N/B, SR175N/B, SR190EBJ, SR190EBQ, SR190NGB, SR210J/S, SR220J/H, SR240N, SR240N/B, SZ110B, SZ120P/B • SZ4VWN/X, SZ5MN/B, SZ5VWN/X, SZ24, SZ51B/B, SZ52B/B, SZ53B/B, SZ71B/B, SZ72B/B, SZ73B/B, SZ80PS, SZ80S, SZ81PS, SZ81S, SZ82PS, SZ82S, SZ83HS, SZ83NS, SZ90PS, SZ90S, SZ91PS, SZ91S, SZ92PS, SZ92S, SZ93HS, SZ93NS, SZ93S, SZ140, SZ140PC, SZ140PD, SZ150, SZ160P, SZ160P/C, SZ170P, SZ170P/C, SZ230P/B, SZ270P/C, SZ320P/B, SZ330P/B, SZ340, SZ340P, SZ360P/C, SZ370P/C, SZ381P/X, SZ390, SZ390PW1, SZ430N, SZ430N/B, SZ440, SZ450AN, SZ450N/C, SZ460N/C, SZ470N/C, SZ480, SZ491N/X, SZ640, SZ640N/B, SZ640N01, SZ640N02, SZ640N03, SZ640N04, SZ640N05, SZ640N06, SZ640NSA, SZ645P1, SZ645P2, SZ645P3, SZ645P4, SZ650N/C, SZ660N/C, SZ670N/C, SZ680, SZ680N01, SZ680N02, SZ680N03, SZ680N04, SZ680N05, SZ680N06, SZ680N07, SZ691N/C, SZ691N/X, SZ70B/B, SZ750N/C, SZ770N • TZ130N/B, TZ150N/B, TZ150N/N, TZ160N/B, TZ170N/B, TZ170N/N, TZ180N/RC, TZ185N/WC, TZ190N/B, TZ190N/BC, TZ191N/X, TZ195N/XC, TZ198N/RC, TZ250N/P, TZ350N/B • VAIO VGNC25G/W • Z520N/B, Z530N/B, Z550N/B, Z570N/B, Z591U/B, Z70B, Z90F/S, Z90N/S, Z90P/S, Z90S, Z90U/S

TOSHIBA

Tip	Model Name / Number
41	• DynaBook SS 425 • Small Business: 1130, 2430
49	• DynaPad: T200, T200CS • Libretto: 20CT, 30CT, 50CT, 60CT, 70CT, U100, U100-S213, U105

> TOSHIBA

Tip	Model Name / Number
49	• Qosmio: E series, E10, E15-AV101, F10 series, F10-100, F10-124, F10-125, F10-GP1, F15-AV201, F20, F25-AV205 • Small Business: 3500, 6100 • T4500, T4500C, T4600, T4600C, T6000

TOSHIBA PORTEGE

Tip	Model Name / Number
49	• 300CT, 305CT, 310CT, 315CT, 320CT, 325CT, 330CT, 335CT, 600CT, 610CT, 620CT, 650CT, 660CDT, • 2000, 2010, 3500, 3505, 4000, 4005, 4010, 7140, 7200, 7000CT, 7010CDT, 7010CT, 7020CT, 7140CT, 7200CT, 7200CTE, 7220CTE • A600, A600-S2201, A605, A605-P200, A605-P201 • M100 • M200 series, M200, M200-86E, M200-S838, M205-S809, M205-S810, M300, M400-S4031, M400-S4032, M400-S4034, M400-ST4035, M400-ST9113, M405-S8003 • R100, R200, R200-S2031, R200-S2062, R200-S214, R200-S234, R205-S209, R400-10B, R400-100, R400-104, R400-106, R400-S4831, R400-S4832, R400-S4833, R400-S4834, R400-S4835, R400-S4931, R400-S4933, R500-S5001X, R500-S5002, R500-S5002X, R500-S5003, R500-S5004, R500-S5005, R500-S5006V, R500-S5007V, R500-S5008X, R500-S8199, R505, R600, R600-S4201 • S100-S1133, S100-S113TD, S100-S213TD • T3400C, T3400CT, T3400CT/120, T3600C, T3600CT

TOSHIBA SATELLITE

Tip	Model Name / Number
41	• 1000, 1000-S157, 1000-S158, 1000-Z2, 1005, 1005-S157, 1005-S158, 1100, 1100-S101, 1110-S153, 1105, 1110, 1115-S103, 1115-S104, 1115-S107, 1115-S123 • 1130 series, 1130, 1135, 1130-S155, 1130-S156, 1135-S125, 1135-S155, 1135-S156, 1135-S1551, 1135-S1552, 1135-S1553, 1135-S1554, 1730, 1750, 1755, 1900, 1905, 1950 • 1200 series, 1200-S121, 1200-S122, 1200-S252, • 1600 series, 1605CDS, 1620CDS, 1625CDT, 1640CDT, 1670CDS, 1675CDS, 1690CDT, 1695CDT • 1700 series, 1715XCDS, 1730CDT, 1735XCDS, 1755CDT, 1755CE, 1755DVD • 1900 series, 1900-S305 • 1905 series, 1905-S277, 1905-S278, 1905-S301, 1905-S302, 1905-S303, 1905-S304 • 1950 series, 1955-S801, 1955-S802, 1955-S803, 1955-S804, 1955-S805, 1955-S806, 1955-S807 • 2430-S255, 2430-S256, 2435-S255, 2435-S256, • 3000 series, 3000-S304, 3000-S307, 3000-S309, 3000-S353, 3000-S514, 3005-S303, 3005-S304, 3005-S307, 3005-S308, 3005-S309, 3005-S403, 3005-S504 • A80, A80-S178TD • A85 series, A85-S107, A85-S1071, A85-S1072 • A100-S2211TD, A100-S2311TD, A100-S3211TD, A100-S8111TD, A100-ST3211, A105-S101, A105-S1013, A105-S1014, A105-S171, A105-S1711, A105-S1712, A105-S2001, A105-S2011, A105-S2021, A105-S2031, A105-S2041, A105-S2051, A105-S2061, A105-S2071, A105-S2081, A105-S2091, A105-S2101, A105-S2111, A105-S2121, A105-S2131, A105-S2141, A105-S215TD, A105-S2194, A105-S2231, A105-S2236, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S2719, A105-S361, A105-S3611, A110-S1111

> TOSHIBA SATELLITE

Tip	Model Name / Number
41	• L10, L15-S104, L15-S1041, L20, L20-S310TD, L25, L25-S119, L25-S1192, L25-S1193, L25-S1194, L25-S1195, L25-S1196, L25-S121, L25-S1215, L25-S1216, L25-S1217, L35-S1054, L35-S2151, L35-S2161, L35-S2171, L35-S2174, L35-S2194, L35-S2316, L35-S2366, L45-S7409, L45-S7419, L45-S7423, L45-S7424, L45-SP2066 • M30X series, M30X-1592ST, M30X-1593ST, M30X-S171ST, M30X-S181ST, M30X-S191TD, M30X-S221ST, M30X-S221TD • M35X series, M35X-S109, M35X-S111, M35X-S114, M35X-S1141, M35X-S1142, M35X-S1143, M35X-S149, M35X-S1491, M35X-S1492, M35X-S161, M35X-S1611, M35X-S163, M35X-S1631, M35X-S309, M35X-S3091, M35X-S311, M35X-S3111, M35X-S3112, M35X-S329, M35X-S3291, M35X-S349, M35X-S3491, M40-S312TD, M45-S165, M45-S169, M45-S1691, M55-S1001, M55-S139, M55-S1391 • M60 series, M60-S6111TD, M60-S8112ST, M60-S8112TD, M60-S811ST, M60-S811TD, M65-S809, M65-S8091, M65-S8092, M65-S821, M65-S8211, M65-S8213, M65-S9062, M65-S9063, M65-S9064, M65-S9065, M65-S909, M65-S9091, M65-S9092, M65-S9093, • M105-S1011, M105-S1021, M105-S1031, M105-S1041, M115-S1061, M115-S1064, M115-S1071, M115-S1074, M115-S3104 • U300-ST3091, U300-ST3092, U305-S5077, U305-S5087, U305-S5097, U305-S5107, U305-S5117, U305-S5127, U305-S7448, U305-S7467, U305-S7477
49	• 210CDT, 220CDS, 220CS, 220CT, 225CDS, 250, 230CDS, 230CX, 235CDS, 300, 300CDS, 300CDS/2, 305, 305CDS, 305CDS/2, 305CDT, 310CDS, 310CDS/2, 310CDT, 310CDT/2, 310, 315, 315CD, 315CDS, 315CDS/2, 315CDT, 315CDT/2, 320, 320CDS, 320CDT, 320CT, 325, 325CDS, 325CDT, 330, 335, 330CDS, 330CDT, 335CDS, 335CDT • 1400 series, 1400-S151, 1400-S152, 1405-S151, 1405-S152, 1405-S171, 1405-S172, 1410, 1410-S105, 1410-S106, 1410-S173, 1410-S174, 1415-S105, 1415-S106, 1415-S115, 1415-S173, 1415-S174 • 1500 series, 1555, 1805, 2400, 2450, 2800, 2805, 4600, 5000, 5100, 1555CDS • 1800 series, 1800-S202, 1800-S203, 1800-S204, 1800-S206, 1800-S207, 1800-S253, 1800-S254, 1800-S256, 1800-S274, 1805-S154, 1805-S177, 1805-S203, 1805-S204, 1805-S207, 1805-S253, 1805-S254, 1805-S255, 1805-S273, 1805-S274, 1805-S278 • 2060CDS, 2060CDT, 2065CDS, 2065CDT, 2100CDS, 2100CDT, 2100CDX, 2105CDS, 2115CDS, 2140XCDS, 2180CDT, 2210CDT, 2210XCDS, 2215CDS, 2250CDT, 2250XCDS • 2400 series, 2400-S201, 2400-S202, 2400-S251, 2400-S252, 2405-S201, 2405-S202, 2405-S221 • 2410 Small Business Series, 2410-S185, 2410-S203, 2410-S204, 2410-S205, 2410-S206, 2415-S205, 2415-S206, 2455-S3001, 2455-S305, 2455-S306 • 2500 series, 2500CDS, 2500CDT, 2505CDS, 2505CDT, 2510CDS, 2510CDS/4, 2515CDS, 2515CDS/4, 2515CTS, 2520CDT, 2530CDS, 2530CDS/4, 2535CDS, 2535CDS/4, 2540CDS, 2540CDS/4, 2540CDT, 2545CDS, 2545CDS/4, 2545CDT, 2545XCDT, 2545XCDT/4, 2590CDS, 2590CDS/4, 2590CDT, 2590XDVD, 2595CDS, 2595CDS/4, 2595CDT, 2595XDVD • 2600 series, 2610DVD, 2615DVD, 2655XDVD, 2675DVD, 2695DVD • 2700 series, 2710XDVD, 2715DVD, 2715XDVD, 2755DVD, 2755XDVD, 2770XDVD, 2775XDVD, • 2800-S201, 2800-S202, 2805-S201, 2805-S202, 2805-S301, 2805-S302, 2805-S401, 2805-S402, 2805-S503, 2805-S603 • 2900 series

TOSHIBA SATELLITE

Tip	Model Name / Number
49	• 4000CDS, 4000CDS/4, 4000CDT, 4000SCDS/4, 4005CDS, 4005CDS/4, 4005CDT, 4010CDS, 4010CDS/4, 4010CDT, 4015CDS, 4015CDS/4, 4015CDT, 4020CDT, 4020CDT/6, 4025CDT, 4025CDT/6, 4030CDT, 4030CDT/4, 4035CDT, 4060CDT, 4060CDT/4, 4060XCDT, 4070CDS, 4070CDT, 4080CDT, 4080XCDT, 4080XCDT/6, 4085XCDT, 4090CDS, 4090XCDT, 4090XDVD, 4090XDVD/6, 4100XDVD, 4100XDVD/6, 4280ZDVD, 4320ZDVD, 4340ZDVD, 4360ZDVD, • 5000 series, 5005-S504, 5005-S507, 5005-S508, 5105-S501, 5105-S502, 5105-S607, 5105-S608, 5105-S701, 5105-S702, 5105-S901, 5205-S119, 5205-S503, 5205-S504, 5205-S505, 5205-S506, 5205-S5151, 5205-S703, 5205-S704, 5205-S705, 5205-SP505 • A10 Series, A10 • A10-S100 Small Business Series, A10-S100, A10-S127, A10-S128, A10-S129, A10-S167, A10-S169, A10-S177, A10-S178, A10-S1001, A10-S1291, A10-S1691 • A15 Series, A15, A15-S127, A15-S128, A15-S129, A15-S157, A15-S158, A15-S1291, A15-S1292, A15-S1692 • A50 series, A50-AG1, A55-S106, A55-S129, A55-S179, A55-S326, A55-S306, A55-S1063, A55-S1064, A55-S1065, A55-S1066, A55-S1291, A55-S1791, A55-S3061, A55-S3062, A55-S3063, A55-S3261 • A100-SP471, A100-ST1041, A100-ST1042, A100-ST8211, A105-S2201, A105-S4001, A105-S4002, A105-S4004, A105-S4011, A105-S4012, A105-S4014, A105-S4021, A105-S4022, A105-S4024, A105-S4034, A105-S4051, A105-S4054, A105-S4064, A105-S4074, A105-S4084, A105-S4092, A105-S4094, A105-S4102, A105-S4104, A105-S4114, A105-S4124, A105-S4132, A105-S4134, A105-S4164, A105-S4184, A105-S4201, A105-S4204, A105-S4211, A105-S4214, A105-S4224, A105-S4244, A105-S4254, A105-S4274, A105-S4284, A105-S4324, A105-S4334, A105-S4342, A105-S4344, A105-S4364, A105-S4384, A105-S4397, A105-S4547, A105-S45472 • M100-ST5111, M100-ST5211, M105-S3001, M105-S3002, M105-S3004, M105-S3011, M105-S3012, M105-S3014, M105-S3021, M105-S3031, M105-S3041, M105-S3051, M105-S3064, M105-S3074, M105-S3084, M105-S322, M105-SP381, M110-ST1161, M115-S3094, M115-S3144, M115-S3154 • M20 series, M20 • M20-S257 Small Business series, M20-S257, M20-S258 • M30 series, M30 Small Business 2003, M30-001, M30-S309, M30-S3091 • M30-S350 Small Business series, M30-S350, M30-S3501, M30-YSJ • M35 series, M35-S309, M35-S320, M35-S3201, M35-S349, M35-S359, M35-S3591, M35-S3592, M35-S456, M35-S4561, M40, M40-S4111TD, M40-S4112TD, M40-S417TD, M45, M45-S1651, M45-S265, M45-S2651, M45-S2652, M45-S2653, M45-S269, M45-S2691, M45-S2692, M45-S2693, M45-S331, M45-S3311, M45-S351, M45-S3511, M45-S355, M45-S3551, M45-S3552, M45-S3553, M45-S359, M45-S3591, M50-S4182TD, M50-S418TD, M50-S5181TD, M50-S5182TD, M55, M55-S135, M55-S1351, M55-S1352, M55-S2252, M55-S2253, M55-S325, M55-S3251, M55-S3262, M55-S329, M55-S3291, M55-S3292, M55-S3293, M55-S3294, M55-S331, M55-S3311, M55-S3314, M55-S3315, M55-S351, M55-S3511, M55-S3512 • P100-ST1071, P100-ST1072, P100-ST7111, P100-ST7211, P100-ST9012, P100-ST9212, P100-ST9412, P100-ST9612, P105-S6002, P105-S6004, P105-S6012, P105-S6014, P105-S6022, P105-S6024, P105-S6034, P105-S6054, P105-S6062, P105-S6064, P105-S6074, P105-S6084, P105-S6104, P105-S6114, P105-S6124, P105-S6134, P105-S6147, P105-S6148, P105-S6157, P105-S6158, P105-S6167, P105-S6177, P105-S6187, P105-S6197, P105-S6207, P105-S6217, P105-S6227

TOSHIBA SATELLITE

Tip	Model Name / Number
49	• Pro 440CDT, Pro 440CDX, Pro 445CDT, Pro 445CDX, Pro 450CDT, Pro 450CDX, Pro 4600, Pro 460CDT, Pro 460CDX, Pro 465CDT, Pro 465CDX, Pro 470, Pro 470CDT, Pro 480CDT, Pro 480CDX, Pro 485CDT, Pro 485CDX, Pro 490CDT, Pro 490CDX, Pro 490XCDT, Pro 495CDT, Pro 495CDX • Pro 4000 series, Pro 4200, Pro 4260DVD, Pro 4280XDVD, Pro 4280ZDVD, Pro 4300 • Pro 6000 series, Pro 6000, Pro 6100, Pro A10 • Pro M10-S405, Pro M10, Pro M10-S406, Pro M15, Pro M15-S405, Pro M15-S406 • Pro S300, Pro S300-EZ2505, Pro S300-S1001, Pro S300-S2504, • R10-S613, R10-S802TD, R10-S804TD, R10-S820, R15-822, R15-S822, R15-S8222, R15-S829, R20-ST2081, R20-ST4113, R25, R25-S3503, R25-S3513 • T1800, T1850, T1850C, T2100CDX, • U200, U200-ST2091, U200-ST2092, U200-ST3311, U205, U205-S5002, U205-S5021, U205-S5022, U205-S5034, U205-S5044, U205-S5057, U205-S5058, U205-S5067

TOSHIBA TECRA

Tip	Model Name / Number
41	• L2-S011 • M8-8011X, M8-S8011, M8-ST3093, M8-ST3094
49	• 520CDT, 530CDT, 550CDT, 700, 700CDT, 700CS, 700CT, 710CDT, 720, 780, 720CDT, 730CDT, 730XCDT, 740CDT, 750CDM, 750CDS, 750CDT, 750DVD, 780CDM, 780CDV, 780DVD • 8000, 8100, 8200, 9000, 9100 • A1 • A2, A2-S119, A2-S139, A2-S20ST, A2-S219, A2-S239, A2-S316, A2-S336, A2-S4372ST • A3, A3-S711, A3-S731 • A4, A4-S111TD, A4-S211, A4-S216, A4-S231, A4-S236, A4-S312TD, A4-S313 • A5, A5-S116, A5-S237, A5-S416, A5-S516, A5-S6215TD • A6-EZ6311, A6-EZ6312, A6-EZ8312, A6-S513, A6-S713, A6-ST3112, A6-ST3512, A6-ST6315 • A7-S612, A7-S712, A7-ST5112, A7-ST7711 • A8-EZ8311, A8-EZ8312, A8-EZ8313, A8-EZ8314, A8-EZ8412, A8-EZ8413, A8-EZS8414 • A9-S9015X

TWINHEAD

Tip	Model Name / Number
32	• PowerSlim, PowerSlim 600 • SlimNote: EX, EX200TG, EX233TG, EX266TG, GX, SLGX, XL, XL 200TK • P79TE, P85, P86, P93, P98
41	• SlimNote: 910CV, 9133TV, 9133TZ, 9150TZ, 9166TZ, VX, VXE, VXE3, VXE500 • 340S2 • A5000, A5010, A9110, A9110A • P88, P88TE

WINBOOK

Tip	Model Name / Number
32	• XL2, XL3
41	• N3 • Si, Si 566/32, Si 566/64, Si 650 TFT, Si 700, Si 700M, Si 800 TFT, Si 800/128, Si 800CD, Si 800M, Si 850, Si 850DVD • Si2 series, Si2 850 • X505, X510, X512, X540 • XL, XL 300TFT, XLI • XP, XP5 • Z1, Z1 850

#I-5101

20091022